

STIGA

SWS 800 G (2017)


219802532/S16



Spare parts list Reservdelar Repuestos Ersatzteile Pièces détachées Reserve onderdelen Catalogo ricambi


- Use ST. S.p.A. Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative And might Not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair And/Or replacement, make sure that the illustrated parts list Is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

All rights reserved. No part Of this material may be reproduced Or transmitted, in any form Or by any means, electronic Or mechanical, including photocopying, recording Or by any information storage And retrieval system, without permission in writing from ST. S.p.A.




Body

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	118820430/0	Direction Rod			
2	1	118820368/0	Pin			
3	17	112154210/0	Nut			
4	1	118820369/0	Welded Direction Plate			
5	3	1811-3080-01	Cotter Pin			
6	1	118820370/0	Fixing Plate			
7	1	118820371/0	Rotating Rod			
8	1	112793301/0	Screw			
9	1	112523060/0	Washer			
10	1	118820253/0	Pulley			
11	1	118821090/0	Short Shaft Assy			
12	6	112792611/0	Screw			
13	8	9699-0090-02	Washer			
14	2	118820373/0	Plate			
15	1	118820374/0	Short Shaft			
16	1	118820375/0	Key			
17	2	118820376/0	Ball Bearing			
18	1	118820377/0	Bearing Housing			
19	1	118820378/0	Gimbal			
20	2	112154510/0	Nut			
21	4	118820379/0	Cap			
22	2	118820380/0	Shaft			
23	2	118820381/0	Wheel			
24	7	112792611/0	Screw			
25	1	118820382/0	Fixing Plate			
26	4	118821136/0	Screw			
27	2	118820383/0	Plate			
28	4	112691100/0	Screw			
29	1	118820384/0	Fixing Plate			
30	2	1811-3143-01	Sealing			
31	7	112791400/0	Screw			
33	2	118820241/0	Sleeve			
34	1	118820386/0	Worm Gear			
35	1	118820387/0	Ball Bearing			
36	1	112521370/0	Washer			
37	1	118820388/0	Ball Bearing			
38	1	118820389/0	Gasket			
39	1	1811-3144-01	Key			
40	1	118820390/0	Shaft			
41	24	118820391/0	Brush Pad			
42	26	118820392/0	Straight Brush			
43	2	118820393/0	Connector			
44	1	118820431/0	Brush Cover			
45	1	112793301/0	Screw			
46	1	118820395/0	Grease Cup			
48	1	118820397/0	Support			
50	2	112819121/0	Screw			
51	1	118820399/0	Sealing Wheel			




Body

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
52	1	118820400/0	Key			
53	1	1811-3150-01	Ball bearing			
54	2	118820401/0	Steel Sleeve			
55	1	118801147/0	Pin			
56	6	112790781/0	Screw			
57	2	112793301/0	Screw			
58	1	118820402/0	Fixing Plate			
59	6	112521331/0	Washer			
60	1	118820403/0	Belt			
61	2	112792611/0	Screw			
62	1	118820404/0	Belt Cover			
63	2	112521331/0	Washer			
64	2	112582100/0	Grower			
65	1	118820787/0	Gear Box Assy			
66	2	118820736/0	Fixing Plate			




Handle

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	118820405/0	Panel			
2	4	112818900/0	Screw			
3	6	112155000/0	Nut			
4	2	118820433/0	Left Handle			
4	2	118820434/0	Right Handle			
5	2	2132110	Screw			
6	2	112530060/0	Spring Washer			
7	2	118820209/0	Screw			
8	4	118820041/0	Nut			
9	2	118820406/0	Wire			
10	3	118820348/0	Pin			
11	1	118820407/0	Right Lever			
12	3	112154510/0	Nut			
13	2	118820198/0	Handle			
14	1	118820408/0	Left Lever			
15	2	118820409/0	Control Handle			
16	1	118820410/0	Pin			
17	2	1811-3066-01	Spring			
19	2	112691100/0	Screw			
20	1	118820412/0	Gear Rod			
21	1	1811-3080-01	Cotter Pin			




Transmission

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	118820580/0	Tyre	Wheel Assy (Tyre & Rim)		
2	3	112154510/0	Nut			
3	1	118820094/0	Pulley Seat			
4	10	112790781/0	Screw			
5	1	118820299/0	Wire			
6	1	118820300/0	Pulley			
7	1	118820298/0	Sleeve			
8	21	112791200/1	Screw			
10	4	112792611/0	Screw			
11	1	118820149/0	Engine Plate - Grey			
12	7	112154210/0	Nut			
14	1	118820303/0	Belt			
15	2	118820756/0	Drive pulley			
16	2	118820262/0	Gears connector			
17	1	9699-0109-02	Washer			
18	1	112793312/0	Screw			
19	4	112691100/0	Screw			
20	1	118820263/0	Gear Adjuster			
21	2	112674550/0	Screw			
22	1	118820264/0	Gears connector			
23	1	9997-0820-16	Screw			
24	1	118820265/0	Cushion			
25	3	1811-3113-01	Plastic bushing			
26	1	118820308/0	Strut			
27	6	112793701/0	Screw			
28	2	118820266/0	Shaft seat			
29	4	112155000/0	Nut			
30	2	118820157/0	Ball Bearing			
31	1	112609260/0	Seeger			
32	2	118820379/0	Cap			
33	1	118820124/0	Driving Shaft			
34	1	118820126/0	Pin	6x30		
35	1	118820125/0	Key	6x6x22		
36	1	118820222/0	Gear			
37	1	118820122/0	Sleeve			
38	2	118820223/0	Inner Shaft Seat			
39	2	118820152/0	Ball Bearing			
40	1	118820224/0	Hexagon Shaft			
41	1	112609800/0	Seeger			
42	1	118820312/0	Shift bearing			
43	1	118820314/0	Bracket			
44	2	118820110/0	Inner Ring			
45	1	118820317/0	Rubber			
46	1	118820225/0	Gear			
47	2	1811-3064-01	Tension pulley			
48	1	118820334/0	Tensioner			
49	1	118820336/0	Fixing Block			
50	1	118820337/0	Tensioner			




Transmission

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
51	1	118820226/0	Tension Assy			
52	1	1811-3118-01	Spring			
53	1	118820343/0	Brake Spring			
54	1	118820339/0	Pulley			
55	2	1811-3116-01	Bearing Housing			
56	2	118820340/0	Ball Bearing			
57	1	1811-3125-01	Strut			
58	2	1811-3061-01	Spacer bush			
59	1	118820348/0	Pin			
60	1	118820227/0	Connector Assy			
61	1	118820349/0	Spring			
62	1	118820229/0	Plate			
63	1	112156603/0	Nut			
64	2	118820295/0	Strut			
65	1	118820230/0	Bottom Plate			
66	1	118820211/0	Tyre	Wheel Assy (Tyre & Rim)		
67	31	112521330/0	Washer			
68	31	112582100/0	Grower			
69	4	112521350/0	Washer			
70	4	112583500/0	Grower			




Collecting Box

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	2	118820418/0	Hanlde			
2	1	118820437/0	Plate			
3	1	118820438/0	Plate			
4	4	112800815/0	Screw			
5	4	112728099/1	Screw			
6	4	112154210/0	Nut			
7	1	118820439/0	Collecting Box Welded			
8	8	118820030/0	Nut			
9	2	118820417/0	Wheel			




Snow blade

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	2	118820418/0	Hanlde			
2	4	112728099/1	Screw			
3	1	118820436/0	Snow Blade			




Labels

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	114369263/0	Label			
2	1	114369264/0	Label			
3	1	114369269/0	Label			
4	1	114369266/0	Label			
5	1	114369268/0	Label			
6	1	114369267/0	Label			
7	1	114369265/0	Label			




Engine - Starter Assy, Tank

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	118551189/0	Muffler			
3	2	112154210/0	Nut			
4	1	118551190/0	Gasket, Muffler			
5	1	112793102/0	Screw			
6	1	118551185/0	Air Cleaner Assy			
7	1	118551192/0	Knob			
8	1	118551186/0	Air Cleaner Cover			
9	1	112373600/0	Wing Nut			
10	1	118551187/0	Air Filter			
11	1	118551202/0	Gasket			
12	1	118551188/0	Air Cleaner Base			
13	1	118550456/0	Breather Fule Pipe			
14	2	118550806/0	Nut			
15	1	118551191/0	Muffler Protection			
16	2	118550861/0	Screw			
17	1	118551170/0	Guard			
21	1	118551193/0	Starter Assy			
23	1	118551196/0	Stop Switch			
24	1	118551171/0	Cover			
26	1	118550336/0	Nut			
27	1	118551194/0	Starter Cup			
28	1	118551169/0	Starter Cup			
29	1	118550489/0	Flywheel Ass.Y			
30	1	118551195/0	Elettronic Coil			
32	1	9400-0244-00	Spark Plug			
33	2	118550869/0	Screw			
34	1	118551181/0	Remote Control Assy			
35	1	118550810/0	Spring			
36	1	118550811/0	Screw			
37	1	118551179/0	Spring			
38	1	118550807/0	Arm Governor			
39	1	118550805/0	Screw			
40	1	118550806/0	Nut			
41	1	118551178/0	Governor Link			
42	1	118551180/0	Spring			
43	4	112791500/0	Screw			
44	1	118551183/0	Tank Support			
45	1	118551182/0	Tank Support			
46	1	118550504/0	Fuel Pipe			
47	2	118550872/0	Pipe Clip			
48	1	118550500/0	Fuel Tank Hose Connection			
49	1	118550501/0	Fuel Tank			
50	1	118551176/0	Fuel Filter			
51	1	118551177/0	Fuel Cap			
52	4	112790781/0	Screw			



Engine - Piston, Crankshaft

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	4	118550816/0	Screw			
2	1	118550784/0	Cover			
3	1	118551163/0	Gasket			
4	2	118550273/0	Valve Arm Set			
5	1	118550475/0	Valve Lifter			
6	2	118550474/0	Push Rod			
7	2	118550623/0	Valve Lifter			
8	2	118551166/0	Valve keeper			
9	2	118551167/0	Retainer			
10	2	118550896/0	Spring			
11	1	118551168/0	Gasket			
12	1	118551203/0	Valve Assy, Intake + Exhaust			
13	1	118551162/0	Cylinder Head			
14	4	118551200/0	Screw			
15	1	118550783/0	Gasket			
17	2	118550460/0	Drain Plug bolt			
18	2	118550793/0	Washer , Drain Plug			
19	1	118551198/0	Sensor			
20	1	118550869/0	Screw			
21	1	118550379/0	Oil Seal			
22	2	118550280/0	Ball Bearing			
23	1	118550288/0	Woodruff Key			
24	1	118550800/0	Crankshaft			
25	1	118550519/0	Connecting Rod			
26	1	118551164/0	Piston			
27	1	118550786/0	Piston Pin			
28	2	118551201/0	Washer, Piston Pin			
29	1	118551165/0	Piston, Ring Set			
30	1	118550782/0	Crankcase Gasket			
31	1	118551161/0	Crankcase Cover			
32	1	118550379/0	Oil Seal			
33	1	118551160/0	Oil Tank Cap			
34	1	118550624/0	Camshaft assy			
35	1	118550787/0	Speed Governor Assy			
36	1	118550459/0	Shaft, Governor Arm			
37	1	118550858/0	Washer			
38	1	118550856/0	Cotter Pin			
39	1	118551197/0	Oil Level Switch			
40	2	118550816/0	Screw			
41	2	118550299/0	Stud Bolt			
42	1	118551174/0	Carburetor Gasket			
43	1	118551175/0	Intake Manifold			
44	1	118551173/0	Carburetor Gasket			
45	1	118551172/0	Carburettor			
46	1	118551184/0	Air Purge Pump			
47	1	118550482/0	Spacer			
48	2	118550454/0	Stud Bolt			
49	6	118551199/0	Screw			



Engine - Piston, Crankshaft

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
51	1	118551204/0	Engine Assembled			