

STIGA


SCOOP ES (1998)

13-2022-21

Spare parts list **Reservdelar** **Repuestos** **Ersatzteile** **Pièces détachées** **Reserve onderdelen** **Catalogo ricambi**


- Use ST. S.p.A. Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative And might Not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair And/Or replacement, make sure that the illustrated parts list Is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

All rights reserved. No part Of this material may be reproduced Or transmitted, in any form Or by any means, electronic Or mechanical, including photocopying, recording Or by any information storage And retrieval system, without permission in writing from ST. S.p.A.




Chassis Steering

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	4	9997-0890-12	Screw			
2	17	9747-0831-02	Lock Nut			
3	2	1134-3165-01	Tube Plate			
4	2	1134-3113-01	Spacer			
5	3	9997-0830-16	Screw			
6	4	9739-0831-22	Nut			
7	10	9997-0820-16	Screw			
8	4	9699-0090-02	Washer			
9	1	1134-3192-01	Steering wheel			
10	1	1134-0341-01	Washer	1.5 mm		
10	1	1134-0341-02	Washer	0.5 mm		
11	2	9545-0500-00	Valve Assy.			
12	2	1134-9024-01	Bearing	Sats 4 st/kit of 4		
13	1	1134-3190-01	Steering Column			
14	1	1134-3086-01	Sprocket			
15	1	9595-0258-00	Locating Pin			
16	2	1134-3162-01	Spacer			
18	1	1134-3080-02	Toothed Segment			
19	1	1134-1565-01	Spacer			
20	4	9997-0855-12	Screw			
21	2	9699-0056-02	Washer			
22	1	1134-3115-01	Steering Arm			
23	1	1134-3113-01	Spacer			
24	1	1134-2096-02	Tie Rod			
25	2	9675-0015-02	Starlock			
28	1	1134-3140-01	Bumper			
29	2	1134-3726-03	Rim			
30	2	9545-0114-00	Tyre	11 x 4.00 - 4		
31	1	1134-3166-01	Steering Rod Sleeve			
32	5	9599-0080-02	Cotter Pin			
33	1	1134-3118-01	Spindle R.H.	2000		
34	1	1134-3120-01	Spindle L.H.	2000		
35	1	1134-3107-01	Front Axle Bracket			
36	1	1134-3151-01	Front Axle			
37	1	1134-3155-01	Spacer Tube			
38	1	1134-3238-01	Seat			
39	1	9988-3919-16	Screw			
40	1	1134-3135-01	Seat Bracket (Yellow)			
41	1	1134-3138-01	Seat Support			
42	1	1134-0022-00	Control Rod			
43	2	9675-0017-02	Starlock			
44	2	1134-3134-01	Spring			
45	1	1134-3091-01	Engine Hood Yellow			
48	2	1134-3139-01	Tubing			
49	4	9997-0845-12	Screw			
50	1	1134-3247-01	Tie Rod			
51	1	1134-3167-01	Locking Clip			




Chassis Steering

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
52	5	1134-0341-01	Washer			
57A	1	1134-3149-01	Floor Mat-R.H.	Ej ill/not ill.		
57A	1	1134-3149-02	Floor Mat-R.H.	Ej ill/not ill.		
57	1	1134-3537-02	Floor Mat			
58	1	1134-3199-01	Steering Console (Yellow)			
62	1	1134-3281-01	Trim			
99	1	1134-3556-01	Label Kit			
99	1	1134-3922-01	Label Kit			




Engine Transmission

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
6	4	9747-0831-02	Lock Nut			
7	1	1134-3651-01	Engine Pulley			
7A	1	9997-1450-16	Screw	Tillbehör/accessory		
8	1	1134-3141-01	Clutch Lever			
9	2	1134-3144-01	Spacer			
10	5	9849-8013-16	Screw			
11	2	1134-0240-00	Screw			
12	3	1134-3147-01	Washer			
13	3	9699-0056-02	Washer			
14	6	9739-0831-22	Nut			
15	1	1134-9027-01	Tension Roller (Black)			
16	1	9739-1031-22	Nut			
17	1	1134-9013-01	V-Belt	= 9585-0057-00		
18	1	1134-1578-01	Spring			
19	1	1134-2086-01	Belt Stirrup			
20	1	9997-0830-16	Screw			
21	1	1134-3157-03	Transaxle (915-028)	Peerless 915-028A		
21	1	1134-3157-04	Transaxle (915-031)	Peerless 915-031		
22	1	1134-3154-01	Spacer Tube			
23	1	9997-0815-02	Screw			
24	1	9699-0090-02	Washer			
25	1	1134-3182-01	Belt Pulley			
26	1	9600-0050-00	Key			
27	1	9650-0016-04	Circlip			
28	1	1134-3106-01	Pedal Bracket			
29	2	9898-0820-16	Screw			
30	1	1111-0062-01	Control Lever			
31	1	1111-0040-02	Knob			
32	1	9694-0001-00	Washer			
33	1	1134-1597-09	Gas Wire			
34	1	1134-3240-01	Wire Clamp			
35	1	1134-3112-02	Gear Shifter			
36	1	1134-3193-01	Lever Handle			
37	1	1134-1565-01	Spacer			
39	1	1134-3160-01	Gear Shifter Plate			
40	2	9675-0012-02	Locking washer			
41	1	1134-3109-01	Gear Shifter Lever			
42	1	9987-5016-16	Screw			
43	1	9699-0060-02	Washer			
44	1	1134-3845-01	Pedal			
46	1	1111-0158-00	Bushing			
47	1	1134-3047-01	Spacer			
48	1	4231-0013-00	Spring			
49	1	1134-3146-01	Control Rod			
50	1	9599-0067-02	Split Pin			
51	1	9598-0002-02	Elastic Pin			
52	1	1134-3178-01	Plastic Housing			
53	1	1134-3179-01	Parking Brake Lever			




Engine Transmission

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
54	1	1134-3180-01	Spring			
55	3	9997-0520-16	Screw			
56	3	9747-0531-02	Nut			
57	1	9987-5251-12	Screw	3/8" UNF x 51 mm		
61	3	9955-3732-12	Screw			
62	1	9600-0250-00	Key			
73	2	1134-3745-02	Rim			
74	2	9545-0121-00	Tyre	5.30/4.50 - 6		
75	2	9545-0500-00	Valve Assy.			
76	2	1134-3170-01	Bolt			
77	1	1134-3200-01	Shift Rod			
78	1	1134-0149-01	Spacer			
80	1	9997-0855-12	Screw			
85	1	9699-0030-02	Washer			
86	1	1134-3898-01	Oil Pump			
87	1	1134-3870-01	Adapter Plate			
88	3	9997-0830-16	Screw	30 mm		
88	1	9997-0840-16	Screw	40 mm		
89	4	9747-0831-02	Lock Nut			




Electrical system

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	1134-3886-01	Harness			
2	1	1134-3623-02	Interlock Module			
4	2	9849-8013-16	Screw			
5	2	1134-3132-01	Cable Holder			
6	1	1134-3204-01	Cable Holder			
7	1	9579-0003-00	Cable Holder			
8	2	1134-3203-01	Grommet			
10	1	1134-2962-01	Solenoid			
11	2	9794-5131-02	Nut			
12	1	1134-1814-01	Starter Switch Assy.			
12B	1	1134-2852-01	Nut			
12A	1	1134-2853-01	Washer	Ej ill/not ill.		
13	1	1134-2848-01	Ignition Key			
16	1	1134-3897-01	Battery			
17	1	1134-3883-01	Battery Holder			
18	2	9747-0831-02	Lock Nut			
24	1	1134-3399-02	Switch			
25	2	9849-8013-16	Screw			
26	1	1134-3156-01	Switch			
30	1	9799-0831-02	Nut			
32	1	9699-0060-02	Washer			
99	1	1134-3925-01	Battery charger	Tillbehör/accessory		




Mower Deck Controls

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	2	1134-3187-01	Angle Bracket			
2	4	9959-0816-16	Screw			
3	4	9739-0831-22	Nut			
4	1	1134-3189-01	Liftshaft			
5	1	1134-3131-01	Lift Rod			
6	2	9675-0015-02	Starlock			
7	1	1111-1842-01	Spring			
8	1	1134-3129-01	Lift Lever			
9	1	1134-3193-01	Lever Handle			
10	1	1134-3127-01	Angle Bracket			
11	2	9959-0816-16	Screw			
12	2	9739-0831-22	Nut			
13	1	1134-3128-01	Height Adjusting Plate			
14	2	9959-0816-16	Screw			
15	2	9739-0831-22	Nut			
21	1	9699-0062-02	Washer			
22	1	1134-9027-01	Tension Roller (Black)			
23	1	1134-1795-02	Belt Guide			
24	1	9924-0840-19	Screw			
25	1	9739-0831-22	Nut			
26	1	1134-3676-01	Tension Arm			
27	1	1134-1565-01	Spacer			
28	1	9997-0845-12	Screw			
29	1	9699-0090-02	Washer			
30	1	9739-0831-22	Nut			
31	1	1134-1999-01	Brake Pad			
32	1	9959-0816-16	Screw			
33	1	9739-0831-22	Nut			
34	1	1134-3211-01	Spring			
35	1	1134-3560-01	Lever			
36	2	9959-0816-16	Screw			
37	2	9739-0831-22	Nut			
38	1	1134-3207-01	Engaging Lever			
39	1	1134-2849-03	Rubber Hose (60 Mm)			
40	1	1134-3213-01	Spring			
41	1	9595-0209-00	Pin			
42	3	1111-1456-01	Washer			
43	1	1134-3193-01	Lever Handle			
44	1	1134-3212-01	Spring			
52	1	1134-3651-01	Engine Pulley			
55	1	1134-3172-02	Belt Guide			
56	2	9997-0855-12	Screw			
57	2	9739-0831-22	Nut			
62	2	1134-3133-01	Angle Bracket			
63	2	9747-0831-02	Lock Nut			
64	2	9699-0090-02	Washer			
65	3	9598-0002-02	Elastic Pin			



Mower Deck 65S

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	1134-3216-02	Mower Deck (65S) Black			
2	1	1134-3288-01	Transport Blade Lock			
3	2	9898-0820-16	Screw			
4	2	9699-0056-02	Washer			
5	2	9747-0831-02	Lock Nut			
6	1	1134-3682-01	Discharge Shield			
12	1	1134-2147-01	Bearing Box Assy.			
13	1	1134-2083-01	Blade Shaft			
14	1	9549-0014-00	Ball Bearing			
15	1	9549-0027-00	Ball Bearing			
22	4	9959-0820-16	Screw			
23	4	9739-0831-22	Nut			
24	1	1134-3186-01	Belt Pulley	D = 174 mm		
25	1	1134-0323-00	Key			
26	1	9991-1024-19	Screw			
27	1	9699-0030-02	Washer			
28	1	1134-2082-01	Blade Holder			
29	1	1134-3222-01	Blade			
30	1	1134-0323-00	Key			
31	1	9991-1024-19	Screw			
32	2	9959-0830-16	Screw			
33	2	9739-0831-22	Nut			
34	1	1134-9032-01	V-Belt	= 9585-0075-00		



Grass Collector Front Weight

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	1134-3299-01	Grass Ejection Chute			
2	1	1134-3298-01	Grass Ejection Tube			
3	1	1134-3747-01	Cover			
4	1	1134-3220-02	Mounting Frame			
5	1	1134-3232-01	Bag Holder			
6	4	9747-0831-02	Lock Nut			
8	1	1134-3236-01	Frame-Collecting Bag			
12	1	1134-3227-02	Grass Bag			
13	1	1134-3201-01	Bagger Latch			
17	4	9699-0090-02	Washer			
18	2	1134-3301-01	Carr.Bolt			
19	2	9747-0631-02	Lock Nut			
35	2	9997-0860-16	Screw			
36	2	9739-0831-22	Nut			