

STIGA

SC 48 AE (2019)


274141008/S15



Spare parts list Reservdelar Repuestos Ersatzteile Pièces détachées Reserve onderdelen Catalogo ricambi


- Use ST. S.p.A. Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative And might Not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair And/Or replacement, make sure that the illustrated parts list Is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

All rights reserved. No part Of this material may be reproduced Or transmitted, in any form Or by any means, electronic Or mechanical, including photocopying, recording Or by any information storage And retrieval system, without permission in writing from ST. S.p.A.



HH Chain saw Battery

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	118810403/0	Clamp			
2	1	118810480/0	Washer			
3	1	118803294/1	Sprocket			
4	1	4181297	Chain Cover 14inch			
5	1	1519-9116-01	Chain 14"-3/8"-0,050"-52E			
6	2	118803230/0	Terminal			
7	1	118803343/0	Switch			
8	1	118803341/0	Switch			
9	1	118803409/0	Front Handle			
11	1	118803331/0	Guard			
12	1	118803417/0	Guard			
13	1	118803267/0	Spring			
15	1	118800127/0	Guide Bar 14"-3/8"-0,050"			
17	1	118803405/0	Side cover			
20	1	118803243/0	Gear			
21	1	118803297/0	Gear			
22	1	118803273/0	Screw			
25	1	118803465/0	Oil Pump Assy			
26	1	118803248/0	Gear box cover			
28	1	118803261/0	Output shaft			
29	1	118803259/0	Gear			
30	3	6981285	Outfit, Screws			
32	1	2135020	Screw			
33	3	112727790/0	Screw			
34	1	118803247/0	Gear box housing			
36	1	118803254/0	Gear			
37	1	118803332/1	Brushless motor			
38	1	118803427/0	Left description housing			
39	2	112292100/0	Nut			
40	1	118803447/0	Left housing			
41	1	118803312/0	Battery Housing, Left			
42	1	118803302/0	Battery latch			
43	1	118803250/0	Spring			
44	1	118803310/0	Clamp			
45	2	112728523/0	Screw			
46	1	118803325/0	Oil Tube			
47	1	118803434/0	Knob			
48	1	118803453/0	Right Housing			
49	1	118803264/0	Spring			
51	1	118803448/0	Trigger			
53	1	118803339/0	Switch			
54	1	118803311/0	Battery Housing, Right			
55	1	118803444/0	Crankcase	Grey		
55	1	118803445/0	Crankcase	Black		
56	1	118803468/0	PCB components	To 31-may-2017		
56	1	118803468/1	PCB components	From 01-june-2017		
57	1	118803319/0	Oil Tank			
58	1	118803348/0	Oil Tank Cap			



HH Chain saw Battery

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
59	1	118803365/0	Valve			
60	1	118804141/0	Spacer			
62	1	118804135/0	Cable			
63	2	2132530	Screw			
64	2	1126-1049-01	Screw			
65	2	2132590	Screw			
66	2	6981285	Outfit, Screws			
67	4	118804137/0	Heat Shrinkable Tube			
69	1	118804139/0	Light Mat			
70	1	118804140/0	Starting Power Panel			
71	2	112727810/0	Screw			
72	4	123878021/0	Screw			
73	2	112728449/0	Screw			
74	1	112727794/0	Screw			
75	1	114368603/0	Label, Stiga			
76	1	118810709/0	Oil Hose			
80	1	118804992/0	Clutch Cover Assy			
81	1	118804993/0	Housing Kit			
82	1	118804994/0	Front Handle Guard Kit			
83	1	118804995/0	Battery Housing Kit			
84	1	118804996/0	Lever and Switch Kit			
85	1	118804997/0	Oil Tank Assy			
86	1	118804998/0	Electric Motor Assy			