

# STIGA


## SP 340 (2006)

15-4110-11

### **Spare parts list** **Reservdelar** **Repuestos** **Ersatzteile** **Pièces détachées** **Reserve onderdelen** **Catalogo ricambi**

- Use ST. S.p.A. Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative And might Not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair And/Or replacement, make sure that the illustrated parts list Is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.


All rights reserved. No part Of this material may be reproduced Or transmitted, in any form Or by any means, electronic Or mechanical, including photocopying, recording Or by any information storage And retrieval system, without permission in writing from ST. S.p.A.



# Starter


Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	4252340	Carter Assy Yellow			
2	1	3784030	Starter Cord			
3	1	3750067	Starter Handle			
4	3	2123030	Screw			
5	1	4611480	Starter Spring			
6	1	3623590	Bushing			
7	1	3723640	Disc For Starter Spring			
8	1	3750130	Starter Pulley			
9	2	3750080	Starter Hook			
10	1	3750140	Starter Hook Guide			
11	1	3657480	Retainer			

Crankshaft and cylinder



## Crankshaft and cylinder



Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	2432050	Nut			
2	1	2312080	Flat washer			
3	1	3L4541210/1	Flywheel	From 01-September-2005		
3	1	4541210	Flywheel	To 31-August-2005		
4	1	3151010	Flywheel Key			
5	1	3121071	Seal Ring	5a		
5	1	3121072	Seal Ring	5b		
6	2	3112030	Ball Bearing			
7	2	3614480	Washer			
8	1	3L4251960/1	Crankshaft assy			
9	1	3750311	Oil Pump Cap			
10	1	3L4252200/1	Clutch Ass.Y			
11	1	3114190	Needle Bearing			
12	1	4121208	Clutch Drum			
13	1	3612620	Washer			
14	1	112000955/0	Benzing Ring			
15	2	3356050	Circlip Ring			
18	1	3158260	Piston Pin			
19	1	3116100	Needle Bearing			
20	4	2135030	Screw			
21	4	2330020	Washer			
22	1	3123220	Piston Ring Ø 39			
23	1	3L8541360/1	Piston Assy			
24	1	3L8541370/1	Cylinder - Piston Ass'Y			
25	1	3210024	Spark Plug			
26	1	3748880	Spark plug cap			
27	1	3657050	Spark Plug Spring			
28	1	3721530	Protection			
29	1	3210970	Stop Switch			
32	1	3211380	Ground Cable			
33	1	3L3211350/1	Electronic Coil			
34	1	3654480	Spring			
35	2	2321150	Washer			
36	2	2123140	Screw			
37	1	2123020	Screw			



# Carburettor

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	2	2135040	Screw			
2	1	4122040	Muffler Assy			
3	1	3724270	Muffler Gasket			
5	1	3786130	Fuel Line			
7	1	3743407	Choke Lever			
8	1	8744781	Intake Manifold Assy			
9	2	2135210	Screw			
10	1	3745650	Grommet Air-Lever			
11	1	123054003/2	Carburetor			
12	1	3724160	Heat Block			
13	1	4252480	Throttle Cable With Sheath			
14	1	3750180	Intake Manifold			
15	1	3724300	Intake Manifold Gasket			
16	1	3744740	Air Purge Pump			
18	1	8724091	Diaphragm Gasket Set			
19	1	8724300	Gasket Set			
20	2	3721560	Cylinder Gasket			
21	1	3211690	Earth Cable			

Crankcase-trim group






## Crankcase-trim group


Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
2	1	4252010	Tank Cap			
3	1	4252010	Tank Cap			
4	1	4252220	Oil Pump Assy			
5	1	3744790	Spacer			
6	2	2123020	Screw			
7	1	3614810	Retainer			
8	1	323900110/0	Bar			
9	1	2653470	Screw			
10	1	123878001/0	Screw			
11	1	3641970	Chain Tightener Block			
12	1	3741360	Oil Supply Cap			
13	1	3614930	Insert			
14	1	3L4353090/1	Oil Tube Assy			
15	1	323311002/0	Bar Plate			
16	1	4113702	Chain 14inch			
17	1	4252330	Clutch Housing Assy Yellow			
18	1	3786050	Fuel Line			
19	1	4253290	Intake Filter			
20	1	2670270	Nut			
21	1	323650100/0	Screw			
22	1	4253680	Breather Valve Assy			
23	1	2123060	Screw			
24	1	4181297	Chain Cover 14inch			
28	1	2123060	Screw			

Crankcase



## Crankcase

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	3614740	Brake Band			
2	1	2312150	Washer			
3	1	2123060	Screw			
4	1	4252310	Chain Brake Lever			
5	1	3180500	Roller			
6	1	3614780	Spring			
8	2	2123100	Screw			
9	1	3654420	Brake Spring			
10	1	3614490	Brake Plate			
11	1	3180510	Roller			
12	1	3614330	Bushing			
14	3	2123030	Screw			
15	1	4252350	Cylinder Cover Yellow			
16	1	4563267	Hand Guard			
17	1	8781530	Air Filter			
19	1	3750227	Air Purge Cap Button			
20	1	3654430	Spring			
21	1	3750217	Air Purge Pump			



## Handle

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	4563147	Hand Grip			
2	1	4563157	Handle Cover			
3	1	3743587	Throttle Lever For Cable			
4	1	1L3654440/1	Molla Leva Accel. E Sicurezza 360-41			
5	1	3743597	Safety Lever			
6	3	3654400	Spring			
7	2	3614800	Washer			
8	3	2123100	Screw			
9	6	2123031	Screw			
10	1	2135040	Screw			
11	1	2432040	Nut			
12	3	2312090	Flat washer			