

STIGA

Collector 140e Kit (2023)


291382068/ST2

Spare parts list
Reservdelar
Repuestos
Ersatzteile
Pièces détachées
Reserve onderdelen
Catalogo ricambi




- Use ST. S.p.A. Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative And might Not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair And/Or replacement, make sure that the illustrated parts list Is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

All rights reserved. No part Of this material may be reproduced Or transmitted, in any form Or by any means, electronic Or mechanical, including photocopying, recording Or by any information storage And retrieval system, without permission in writing from ST. S.p.A.




Wheels, Blade, Motor, Grasscatcher

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	118811089/0	Blade Bolt			
2	1	112585100/0	Washer			
3	1	118811210/0	Blade			
4	1	118811091/0	Blade Hub			
5	1	118811178/0	Electric Motor			
6	2	118811093/0	Hub Cap			
7	2	118811087/0	Wheel			
8	1	118811211/0	Front axle			
9	6	118811180/0	Plate			
10	8	124487995/0	Cotter Pin			
11	2	118811181/0	Hub Cap			
12	2	118811182/0	Wheel			
13	1	118811212/0	Rear axle			
14	30	112728099/1	Screw			
15	1	118811213/0	Conveyor			
16	1	118811185/0	Height Adjustment Lever			
17	1	112726389/0	Screw			
18	1	118811186/0	PCB Board			
20	1	118811188/0	Battery Housing			
21	1	118811099/0	Safety Key			
28	1	118811215/0	Grasscatcher Handle Kit			
29	1	118811235/0	Grasscatcher Upper Part			
30	1	118811236/0	Fabric Box			
31	1	118811237/0	Grasscatcher Frame			
32	1	118811217/0	Height Adj Levers Kit			
33	1	118811218/0	Height Adj Plate Kit			
41	1	118811221/0	Stoneguard Assy			
42	1	118811232/0	Battery Connection Assy			



Handle

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
14	20	112728099/1	Screw			
19	1	118811214/0	Aesthetic Covers Kit			
22	6	112728535/0	Screw			
23	6	2312150	Washer			
24	2	118811189/0	Lower handle			
25	2	112815255/0	Cup Square Bolt M6X20			
26	1	118811190/0	Upper Handle			
27	2	112727810/0	Screw			
34	1	118811219/0	Aesthetic Covers Kit			
35	1	118811220/0	Battery Cover Kit			
36	1	118811200/0	Left Handle Joint Kit			
37	1	118811201/0	Right Handle Joint Kit			
38	1	118811202/0	Lower Handle Knob Kit			
39	1	118811203/0	Upper Handle Knob Kit			
40	1	118811204/0	Dead Hand Switch Kit			
43	1	118811368/0	Handle Knobs Kit	Includes 2x pos. 38, 39 + Cable Clamp		
44		118811489/0	Ferrite Bead			



Please Note: These images are for illustrative purposes only.
For more info see descriptions.

Battery

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	271012008/ST1	E 22			
1	1	271014000/21	B 24			
1	1	271014008/ST1	E 24			
2	1	271020000/21	C 215 S			
2	1	271020100/21	C 215 D			
2	1	271021000/21	C 215 SU			
2	1	271021100/21	C 215 DU			