

STIGA

SNOW ELECTRIC 31 (2015)


18-2809-31



Spare parts list Reservdelar Repuestos Ersatzteile Pièces détachées Reserve onderdelen Catalogo ricambi


- Use ST. S.p.A. Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative And might Not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair And/Or replacement, make sure that the illustrated parts list Is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

All rights reserved. No part Of this material may be reproduced Or transmitted, in any form Or by any means, electronic Or mechanical, including photocopying, recording Or by any information storage And retrieval system, without permission in writing from ST. S.p.A.



Electric showel

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	1811-2877-01	Handle Assy Yellow	Yellow		
1	1	1811-2878-01	White Handle Assy	White		
2	1	1811-2701-01	Connect cable			
3	1	1811-2700-01	Pipe plug			
4	1	1811-2879-01	Bushing			
5	1	1811-2702-01	Power cord			
6	3	1811-2703-01	Nut			
7	2	1811-2880-01	Knob			
8	3	1811-2704-01	Washer			
9	1	1811-2705-01	Adjustable handle			
10	1	1811-2706-01	Screw			
11	1	1811-2708-01	Handle			
12	1	1811-2707-01	Screw			
13	1	1811-2709-01	Telescopic handle assy			
14	1	1811-2710-01	Step bolt			
15	1	1811-2712-01	Bracket			
16	2	1811-2713-01	Screw			
17	2	1811-2711-01	Nut			
18	1	1811-2881-01	Housing, Yellow	Yellow		
18	1	1811-2882-01	Housing, White	White		
19	7	1811-2714-01	Screw			
20	1	1811-2715-01	Pipe plug			
21	1	1811-2717-01	Motor plate			
22	2	1811-2716-01	Screw			
23	1	1811-2719-01	Overload protection			
24	5	1811-2718-01	Screw			
25	1	1811-2720-01	Brush holder			
26	1	1811-2722-01	Bottom			
27	10	1811-2725-01	Screw			
28	1	1811-2723-01	Plate			
29	4	1811-2721-01	Nut			
30	1	1811-2724-01	Cover-RH			
31	2	1811-2726-01	Nut			
32	3	1811-2727-01	Washer			
33	1	1811-2728-01	Spacer			
34	1	1811-2729-01	Screw			
35	1	1811-2731-01	Auger			
36	1	1811-2730-01	Bearing			
37	4	1811-2732-01	Washer			
38	4	1811-2733-01	Screw			
39	1	1811-2734-01	Scraper Blade			
40	1	1811-2735-01	Plate			
41	1	1811-2736-01	Shaft			
42	1	1811-2737-01	Pulley			
43	2	1811-2738-01	Screw			
44	1	1811-2739-01	Belt			
45	1	1811-2740-01	Cover-LH			
46	1	1811-2741-01	Screw			



Electric showel

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
47	1	1811-2742-01	Screw			
48	1	1811-2743-01	Bracket			
49	1	1811-2744-01	Fixed Plate			
50	1	1811-2745-01	Bearing			
51	1	1811-2746-01	Holder			
52	1	1811-2747-01	Spring			
53	1	1811-2748-01	Pulley			
54	1	1811-2749-01	Engine			