

# STIGA

## SNOW ELECTRIC 45 (2015)


18-2802-32



### Spare parts list Reservdelar Repuestos Ersatzteile Pièces détachées Reserve onderdelen Catalogo ricambi


- Use ST. S.p.A. Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative And might Not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair And/Or replacement, make sure that the illustrated parts list Is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

All rights reserved. No part Of this material may be reproduced Or transmitted, in any form Or by any means, electronic Or mechanical, including photocopying, recording Or by any information storage And retrieval system, without permission in writing from ST. S.p.A.




## Handle, controls

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	8	9799-0631-02	Nut			
5	2	1811-2652-01	Washer			
6	2	9799-0631-02	Nut			
15	2	9847-7925-16	Screw			
51	1	1811-2657-01	Wire			
52	3	1811-2611-01	Rubber ring			
53	2	9847-7916-16	Screw			
54	1	1811-2665-01	Wire Clamp			
55	1	1811-2656-01	Terminal			
56	1	1811-2620-01	Handle			
57	1	1811-2661-01	Cord hook			
58	1	1811-2664-01	Clamp ring			
59	2	1811-2663-01	Plug			
60	4	1811-2666-01	Carriage bolt			
61	4	1811-2658-01	Knob			
62	1	1811-2619-01	Frame-middle			
63	2	1811-2660-01	Wire Clamp			
64	2	1811-2662-01	Plug			
65	1	1811-2618-01	Frame-lower			
66	4	9997-0630-12	Screw			
67	1	1811-2617-01	Rocking handle cover			
68	3	1811-2667-01	Circlip for shaft			
69	1	1811-2616-01	Rocking handle			
70	1	1811-2615-01	Rocking shaft			
71	1	1811-2614-01	Connecting suite			
72	1	1811-2643-01	Screw			
73	3	9941-0416-16	Screw			
74	1	1811-2613-01	Connecting Rod			
75	1	1811-2612-01	Shaft joint			
76	1	1811-2610-01	Direction turn shaft			
77	1	1811-2609-01	Gear bracket			
78	1	1811-2608-01	Gear			
79	4	9683-0025-02	Washer			
80	4	9699-0025-02	Washer			
81	4	9898-0645-12	Screw			



## Covers, el.motor

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	9799-0631-02	Nut			
2	1	1811-2601-01	Knob			
3	1	9898-0635-12	Screw			
4	1	9898-0620-16	Screw			
5	1	1811-2653-01	Washer			
6	1	9799-0631-02	Nut			
7	1	1811-2600-01	Discharge chute cover			
8	1	1811-2646-01	Seal ring			
9	1	1811-2599-01	Discharge chute			
10	1	1811-2597-01	Decoration strip			
11	1	1811-2602-01	Derk-yellow			
12	2	1811-2644-01	Sponge			
13	1	1811-2596-01	Fixed plate			
14	14	9847-7919-16	Screw			
15	5	9847-7925-16	Screw			
16	1	1811-2641-01	Motor fixed clamp			
17	1	1811-2651-01	Motor shroud			
18	5	9549-0043-00	Ball Bearing			
20	1	1811-2645-01	Wind-guide ring			
21	2	1811-2670-01	Screw			
23	1	1811-2650-01	Motor shroud			
24	2	1811-2654-01	Brush holder			
25	2	1811-2647-01	Brush			
26	2	1811-2655-01	Brush holder cover			
27	1	1811-2628-01	Speed changing brkt			
28	4	9847-8016-16	Screw			
29	1	1811-2632-01	Spring			
30	1	9799-0831-02	Nut			
31	1	1811-2629-01	Tensioning bracket			
32	1	1811-2631-01	Tension wheel shaft			
33	1	1811-2626-01	Washer			
34	1	1811-2630-01	Tensioning shaft bolt			
35	1	1811-2637-01	Gearbox			
36	2	1811-2668-01	Screw			
37	2	9941-0408-16	Screw			
38	1	1811-2633-01	Gear-small			
39	2	9847-7709-16	Screw			
40	2	1811-2659-01	Washer			
41	1	1811-2636-01	Shaft			
42	1	9652-0012-04	Circlip			
43	1	1811-2671-01	Ball Bearing			
44	3	9941-0410-16	Screw			
45	3	9683-0010-02	Washer			
46	3	9699-0021-02	Washer			
47	1	1811-2634-01	Gear-big			
48	1	1811-2635-01	Belt wheel-big			
49	1	1811-2638-01	Gearbox cover			
50	4	1811-2669-01	Screw			



## Housing, auger

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
5	1	1811-2653-01	Washer			
6	6	9799-0631-02	Nut			
14	2	9847-7919-16	Screw			
33	2	1811-2626-01	Washer			
42	4	9652-0012-04	Circlip			
50	11	1811-2669-01	Screw			
53	6	9847-7916-16	Screw			
79	3	9683-0025-02	Washer			
80	8	9699-0025-02	Washer			
82	4	9847-7909-16	Screw			
83	1	1811-2604-01	Cover-RH			
84	1	1811-2606-01	Wearing plate-RH			
85	1	1811-2605-01	Wearing plate-LH			
86	1	1811-2598-01	Snow bucket			
87	1	1811-2603-01	Cover-LH			
88	2	1811-2627-01	Wheel			
89	1	1811-2625-01	Wheel Shaft			
90	1	1811-2607-01	Snow shoveling plate			
91	1	9652-0015-04	Circlip			
92	2	9549-0044-00	Ball Bearing			
93	7	9947-0616-16	Screw			
94	2	1811-2623-01	Bearing			
95	1	1811-2622-01	Supporting plate, Right			
96	2	1811-2624-01	Clamp plate			
97	1	1811-2642-01	Auger			
98	1	1811-2621-01	Supporting plate, Left			
99	1	1811-2640-01	Belt wheel-big			
100	1	1811-2639-01	Belt			