

STIGA


SNOW FOX (2013)

18-2869-31

Spare parts list Reservdelar Repuestos Ersatzteile Pièces détachées Reserve onderdelen Catalogo ricambi

- Use ST. S.p.A. Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative And might Not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair And/Or replacement, make sure that the illustrated parts list Is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

All rights reserved. No part Of this material may be reproduced Or transmitted, in any form Or by any means, electronic Or mechanical, including photocopying, recording Or by any information storage And retrieval system, without permission in writing from ST. S.p.A.




Handle, controls

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
10	1	9988-3751-12	Screw			
50	1	1812-0304-01	Spring			
60	1	9699-0029-02	Washer			
70	1	9743-3721-32	Nut			
80	1	1812-2605-01	Lever, Clutch Lh			
100	1	1812-2511-01	Speed Lever			
120	4	9988-3545-12	Screw			
130	1	1812-2417-01	Controls Bracket			
140	1	1812-2751-01	Rod Speed Control			
150	3	9727-3641-22	Nut			
170	2	9794-5131-02	Nut			
175	1	9683-0030-02	Washer			
180	2	1812-2738-01	Bracket, mounting			
190	1	1812-2562-01	Ball Joint			
330	1	1812-2792-01	Dashboard			
340	2	1812-2257-01	Screw			
360	2	1812-2623-01	Shoulder bolt			
370	4	9899-3625-16	Screw			
390	1	1812-2575-01	Support, Dashboard			
400	1	1812-2542-01	Cable, Auger Drive			
410	1	1812-2606-01	Lever, Clutch Rh			
420	2	1812-2256-01	Nut			
430	2	1812-2351-01	Hand Grip			
440	2	1812-2412-01	Spacer			
450	2	1812-2148-01	Spacer			
470	1	1812-2317-01	Upper Handle RH			
480	1	1812-2316-01	Upper Handle LH			
490	2	1812-2479-01	Carriage Bolt	L = 57 mm		
495	2	1812-2476-01	Carriage Bolt	L = 45 mm		
500	1	1812-2519-01	Handle Lower Part			
510	4	120001085/0	Nut		From	
510	4	9743-3621-32	Nut		01-Septem	To
530	4	1812-2641-01	Screw		ber-2017	01-Septem
540	1	1133-0977-01	Cable Adjust Bracket			
550	1	1133-0968-01	Clutch Spring Boot			
560	1	1812-2029-01	Control Cable			
670	5	1812-2371-01	Self lock tie			
680	1	1812-2379-01	Knob			
700	2	9699-0026-02	Washer			
880	2	1812-2765-01	Screw			
930	4	9743-3521-32	Nut			
940	1	1812-2481-01	Screw			
950	1	1812-2256-01	Nut			


Starter

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
10A	1	795027	Fuel cap			
50	4	9899-3638-12	Screw			
60	4	1812-1681-01	Push Retainer			
70	4	9743-3621-32	Nut			
90	1	1812-1719-01	Engine Pulley			
100	3	1812-2248-01	Washer			
110	1	9987-5132-12	Screw			
120	1	1812-2220-01	Belt			
130	1	1812-2784-01	Belt-auger			
140	1	1812-2443-01	Belt Guide			
150	4	9683-0030-02	Washer			
160	1	9987-5119-16	Screw			
170	1	1812-1722-01	Idler Bracket			
180	1	1812-1705-01	Bushing			
190	1	1812-1830-01	Spring			
200	2	1812-2077-01	Tension Roller			
210	2	9743-3721-32	Nut			
220	1	9899-3732-16	Screw			
230	1	1812-2796-01	Auger idler			
240	1	1812-2822-01	Spacer			
260	1	1812-2884-01	Control Arm			
270	1	1812-2813-01	Hair pin			
280	1	1812-2407-01	Clevis Pin			
290	1	1812-2465-01	Bottom Cover			
300	10	1812-2250-01	Screw			
310	1	1812-1676-01	Tension Spring			
320	1	1812-3087-01	Frame			
350	6	1812-2141-01	Screw			
360	1	1812-3073-01	Belt cover			
370	2	1812-2748-01	Screw			
390A	1	1812-2505-01	Foam seal			
390	1	1812-2887-01	Plate, Seal, Black			
400	1	1812-2614-01	Strip, Seal			
410	2	9987-5125-16	Screw			
420	1	1812-2281-01	Cotter Pin			
500	1	1812-2657-01	Washer			
510	1	9699-0038-02	Washer			
520	2	9677-0006-02	Lock washer			



Drive

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
200	1	1812-1686-01	Chain			
210	4	1812-1178-01	Bearing & Retainer			
220	5	1812-1204-01	Washer			
230	8	1812-2249-01	Screw			
240	1	1812-1688-01	Chain			
250	5	1812-1672-01	Retainer Ring			
260	1	1812-2076-01	Spring Link			
300	3	1812-2410-01	Spring			
310	1	1812-2773-01	Sprocket set			
320	2	9699-0038-02	Washer			
330	1	1812-1713-01	Axle-Swing Plate			
340	1	1812-1862-01	Axle Shaft			
350	1	1812-1755-01	Screw			
420	1	1812-1712-01	Sprocket & Hub			
430	2	1812-1724-01	Axle Bearing			
440	1	1812-1750-01	Hex Shaft			
450	1	1812-2734-01	Hub			
460	1	1812-9028-01	Friction Wheel			
500	3	9988-3516-16	Screw			
510	3	9795-3531-02	Nut			
520	1	1812-2380-01	Retext Ring			
530	1	1812-1674-01	Nut			
540	1	1812-1701-01	Swing Plate			
550	1	1812-1739-01	Spacer			
560	1	1812-1725-01	Friction Pulley			
600	1	1812-1720-01	Yoke Rod			
610	1	1812-1219-01	Plastic Bushing			
620	2	9743-3521-32	Nut			
630	1	9988-3538-12	Screw			
640	1	1812-1205-01	Spool			
650	1	1812-1702-01	Bracket			
660	1	1812-1727-01	Drive Cable-Lower			




Muffler

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
10	1	1812-2777-01	Wheel & tire assy-LH	13 x 5.0		
20	1	1812-2776-01	Wheel & tire assy-RH	13 x 5.0		
30	2	1812-2139-01	Retainer Ring			
40	2	1812-0407-01	Washer			
60	1	1812-1114-01	Bolt			
70	1	1812-1760-01	Nut			
80	1	1812-0408-01	Clik Pin			


Auger housing

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
10	1	1812-2774-01	Auger housing	24"		
20	1	1812-2778-01	Impeller housing			
30	1	1812-2789-01	Chimney			
40	1	1812-2779-01	Bracket, rear mount			
50	14	-	-	SCREW, Hex Washer Head, Taptite, 1/4-20 x 3/8		
55	2	1812-2619-01	Screw			
60	1	1812-2783-01	Skid shoe-LH			
70	1	1812-2782-01	Skid shoe-RH			
80	1	1812-2785-01	Scraper bar			
100	8	9743-3521-32	Nut			
110	1	1812-2400-01	Cleanout Brush			
150	2	1812-2413-01	Spring Clamp			
160	2	1812-2480-01	Screw			
170	2	1812-1912-01	Nut			
180	2	1812-0878-01	Bearing			
190	6	9988-3619-16	Screw			
200	3	9727-3641-22	Nut			
210	1	1812-2142-01	Bearing Retainer			
220	1	1812-2346-01	Greased Bearing			
230	6	9743-3621-32	Nut			
240	2	9899-3516-16	Screw			
250	3	9899-3622-16	Screw			
300	6	1812-2254-01	Carriage Bolt			
310	2	1812-1317-01	Universal Housing			




Gear case, auger

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
10	1	1812-2791-01	Auger-RH			
20	1	1812-2790-01	Auger-LH			
30	1	1812-9029-01	Shear Pin Kit			
40	2	1812-2563-01	Cotter Pin			
50	1	1812-1609-01	Key			
60	1	1812-2793-01	Auger pulley			
70	1	1812-2804-01	Gear case assy	24"		
80	1	1812-2780-01	Impeller			
90	1	1812-2553-01	Hub, Impeller			
100	3	1812-2249-01	Screw			
110	3	1812-2640-01	Screw			
120	1	1812-1739-01	Spacer			





Gear case

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
10	1	1812-2781-01	Impeller shaft			
30	1	1812-2786-01	Auger shaft			
40	1	1812-1321-01	Thrust Collar			
50	1	1133-0395-01	Roll Pin			
60	4	1812-0857-01	Thrust Washer			
70	1	1812-0285-01	Needle Bearing			
80	3	1812-1360-01	Bushing			
90	3	1812-0881-01	Oil Seal			
100	1	1812-1359-01	Bushing			
110	1	1812-0908-01	Gear case LH			
120	1	1812-0909-01	Gear case-R.H.			
130	1	1812-0856-01	Screw			
150	1	1812-1371-01	Woodruff Key			
160	1	1812-2798-01	Worm gear			
170	7	1812-1758-01	Nut			
180	1	1812-1361-01	Gasket			
190	7	120001068/0	Screw		From 01-September-2016	
190	7	9988-3519-16	Screw			To 31-August-2016



Chute, crank

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
10	1	1812-2803-01	Chute			
20	1	1812-2805-01	Wing Knob			
40	1	1812-2795-01	Chute rotation assy			
100	4	9743-3521-32	Nut			
110E	1	1812-0203-01	Bushing			
110A	1	1812-0318-01	Handle			
110B	1	1812-1171-01	Washer			
110C	1	1812-1483-01	Nut			
110G	1	1812-1707-01	Chute Crank			
110D	1	1812-1821-01	Eye Bolt			
110H	1	1812-2490-01	Hair Pin			
110F	2	9743-3721-32	Nut			
140I	1	1812-1316-01	Universal Pin			
140J	1	1812-1317-01	Universal Housing			
140H	1	1812-1318-01	Clevis Pin			
140D	1	1812-1706-01	Chute Rotation Gear			
140G	1	1812-1708-01	Yoke Adapter			
140B	1	1812-1761-01	Spring			
140E	1	1812-1791-01	Hair Pin			
140A	1	1812-1826-01	Yoke & Rod			
140C	1	1812-2108-01	Washer			
140K	1	1812-2794-01	Mounting bracket			
140F	1	9599-0033-00	Split Pin			
150	1	9743-3521-32	Nut			
160	2	9699-0035-02	Washer			
170	1	9743-3721-32	Nut			
180	4	1812-2772-01	Screw			
190	1	1812-1678-01	Carriage Bolt			
200	3	1812-2771-01	Screw			
370	1	1812-2381-01	Chute Guard			
380	1	1812-2416-01	Chute Guard Bracket			
390	2	1812-2426-01	Grommet			
400	2	1812-2478-01	Nut			
410	2	1812-2807-01	Screw			
420	1	9899-3516-16	Screw			



Labels

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	1812-2806-01	Label kit	Pos A-I incl.		